

Car Type	Product	NPR Product Code	Engine Model	CC	NO. Cyl.	Reference
TOYOTA	NPR Piston Ring	SWT10201ZZ	1SZ	997	4	13011-23040 13011-23041
TOYOTA	NPR Piston Ring	SWT10104ZZ	1E-L	1000	4	13011-10070 13011-10080 13011-10081
TOYOTA	NPR Piston Ring	SWT10029ZZ	2K	993	4	13011-12030 13011-12010 (500) 13011-12031 (777)
TOYOTA	NPR Piston Ring	SWT10105ZZ	2E-L	1295	4	13011-11040 13011-11041 13011-11060 13011-11061 13011-11072
			2E-Lu			
TOYOTA	NPR Piston Ring	SWT10143ZZ	3E	1456	4	13011-11061 13011-11090
TOYOTA	NPR Piston Ring	SWT10117ZZ	1N-T	1453	4	13011-55010 13011-55011
TOYOTA	NPR Piston Ring	SWT10128ZZ	4E-FE	1331	4	13011-11122 13011-11140
TOYOTA	NPR Piston Ring	SWT10164ZZ	4E-FE	1331	4	13011-11170 13011-11180
TOYOTA	NPR Piston Ring	SWT10052ZY	K	1077	4	13011-22011 13011-24010 13011-24011 13011-24012 (777) 13011-24020 13011-24030
				1166		
			3K	1290		
			4K			
TOYOTA	NPR Piston Ring	SWT10109ZZ	4K-E	1290	4	13011-13010 13011-13060
TOYOTA	NPR Piston Ring	SWT10073ZZ	1G	1988	6	13011-70010 13011-70030
TOYOTA	NPR Piston Ring	SWT10218ZZ	1G-G	1988	6	13011-70070 13011-70040 13011-70061
TOYOTA	NPR Piston Ring	SDT10212ZZ	1G-GEU		6	13011-88300
TOYOTA	NPR Piston Ring	SWT10170ZZ	1G-FE	1988	6	13011-70110
TOYOTA	NPR Piston Ring	SXT10004ZZ	M	1988	6	13011-41011 13011-41015 13011-41040
			2M			
TOYOTA	NPR Piston Ring	SWT10192ZZ	2NZ-FE	1298	4	13011-21050 13011-21041
			1NZ-FE			

TOYOTA	NPR Piston Ring	SWT10211ZZ	2NZ-FE2	1298	4	13011-21060
TOYOTA	NPR Piston Ring	SWT10068ZX	2A	1295	4	13011-14010 13011-14020 13011-14021
TOYOTA	NPR Piston Ring	SWT10009ZZ	3P 4P	1345	4	13011-23030
TOYOTA	NPR Piston Ring	SWT10078ZX	1A 3A	1452	4	13011-15010 13011-15011 13011-15020 13011-15021 13011-15031
TOYOTA	NPR Piston Ring	SWT10014ZZ	2R	1490	4	13011-31010 (500) 13011-31030 13011-31040
TOYOTA	NPR Piston Ring	SWT10161ZZ	5A	1498	4	13011-15050
TOYOTA	NPR Piston Ring	SWT10181ZZ	5A-F	1498	4	13011-15100 13011-15120
TOYOTA	NPR Piston Ring	SWT10183ZZ	1ZZ 1ZZ-FE 3ZZ	1749	4	13011-22030 13011-22040 13011-22100 13011-22111 13011-22200
TOYOTA	NPR Piston Ring	SWT10039ZZ	T	1407	4	13011-25010 (500) 13011-25020 (500) 13011-25032 (777) 13011-25041
TOYOTA	NPR Piston Ring	SXT10041ZZ	4M	2563	6	13011-45021 13011-45040 (777)
TOYOTA	NPR Piston Ring	SXT10060ZZ	T-U	1407	4	13011-25042 13011-25033
TOYOTA	NPR Piston Ring	SWT10042ZZ	12R	1587	4	13011-31050 13011-31051 13011-31060 13011-31061 13011-31070 13011-31090
TOYOTA	NPR Piston Ring	SWT10080ZZ	1S-U	1832	4	13011-63010 13011-63011 13011-63020 13011-63030 13011-63031
TOYOTA	NPR Piston Ring	SWT10099ZZ	5K	1486	4	13011-13040 13011-13050 13011-13090

TOYOTA	NPR Piston Ring	SWT10160ZZ	7K	1781	4	13011-13100
TOYOTA	NPR Piston Ring	SWT10169ZY	7K-E	1781	4	13011-13110 13011-13120
TOYOTA	NPR Piston Ring	SWT10101ZZ	4AGEU	1587	4	13011-16050 13011-16070
TOYOTA	NPR Piston Ring	SWT10108ZZ	4A-L	1587	4	13011-16010 13011-06011 13011-16031 13011-16032 13011-16030
			4A-LC			
TOYOTA	NPR Piston Ring	SWT10142ZZ	4A-FE	1587	4	13011-16140 13011-16150
TOYOTA	NPR Piston Ring	SWT10145ZZ	4A-GZE	1587	4	13011-16050 13011-16090 13011-16180
TOYOTA	NPR Piston Ring	SWT10150ZZ	4AGE	1587	4	13011-16200
TOYOTA	NPR Piston Ring	SWT10156ZZ	4A-G	1587	4	13011-16280 13011-16290 13011-16300
TOYOTA	NPR Piston Ring	SWT10156ZZ	7A-FE	1762	4	13011-16320
TOYOTA	NPR Piston Ring	SWT10196ZZ	2ZZ	1796	4	
TOYOTA	NPR Piston Ring	SWT10123ZZ	4S	1838	4	13011-74110-1 13011-74120-1 13011-74121-1
TOYOTA	NPR Piston Ring	SXT10017ZZ	2U	790	2	13011-11010 13011-11021
TOYOTA	NPR Piston Ring	SWT10072ZX	5M	2759	6	13011-43010 13011-43030
			5ME			
			5MEU			
TOYOTA	NPR Piston Ring	SWT10079ZZ	5MGE	2759	6	13011-43050 13011-43080
			5MEU			
TOYOTA	NPR Piston Ring	SWT10115ZZ	7MGE	2954	6	13011-42010 13011-42011
			7M-GTE			
TOYOTA	NPR Piston Ring	SWT10088ZZ	2SELU	1995	4	13011-74010 13011-74020 13011-74040
TOYOTA	NPR Piston Ring	SXT10067ZZ	21R	1972	4	13011-37010
TOYOTA	NPR Piston Ring	SWT10076ZZ	21R	1972	4	13011-37030 13011-37050 13011-37060

TOYOTA	NPR Piston Ring	SWT10102ZZ	21R	1972	4	13011-37070 13011-37071
			21RC			
TOYOTA	NPR Piston Ring	SWT10040ZZ	2T	1588	4	13011-26020 13011-26041 13011-26040 13011-27020
			2T-C			
			12T			
TOYOTA	NPR Piston Ring	SWT10059ZZ	2T	1588	4	13011-28010 13011-28011 13011-28020 (777) 13011-28030 13011-28071 (777)
			3T	1770		
TOYOTA	NPR Piston Ring	SWT10019ZZ	6R	1700	4	13011-31010 (777) 13011-33020 13011-33021 (777) 13011-33022 13011-33030
			7R	1591		
			8R	1858		
TOYOTA	NPR Piston Ring	SWT10090ZY	1Y	1626	4	13011-71010 13011-71020 13011-71030 13011-72020
			2Y	1812		
			3Y	1998		
TOYOTA	NPR Piston Ring	SWT10119ZZ	3S-FE	1998	4	13011-74070-A 13011-74072 13011-74091 13011-74280 13011-74080 13011-74081
TOYOTA	NPR Piston Ring	SWT10186ZZ	1AZ	1998	4	13011-28120
TOYOTA	NPR Piston Ring	SWT10176ZY	1AZ	1998	4	13011-28130
TOYOTA	NPR Piston Ring	SDT10185ZZ	1TR	1998	4	13011-75100
TOYOTA	NPR Piston Ring	SWT10216ZZ	1JZ	2500	6	13011-46030
TOYOTA	NPR Piston Ring	SWT10125ZZ	1RE	1998	4	13011-75020 13011-75080
			1RZ			
TOYOTA	NPR Piston Ring	SWT10134ZZ	2JZ-GE	2997	6	13011-46040 13011-46041 13011-46050
TOYOTA	NPR Piston Ring	SWT10141ZZ	3S-GTE	1998	4	13011-88363 13011-88380
			3S-GELC			
TOYOTA	NPR Piston Ring	SWT10162ZY	3S-FE	1998	4	13011-74340
TOYOTA	NPR Piston Ring	SWT10133ZZ	5S-FE	2163	4	13011-74261 13011-74290 13011-74260 13011-74300
TOYOTA	NPR Piston Ring	SWT10149ZZ	5S-FE	2163	4	13011-74150

TOYOTA	NPR Piston Ring	SWT10166ZZ	5S-FE	2163	4	13011-74380 13011-74370
TOYOTA	NPR Piston Ring	SWT10171ZZ	5S-FNE	2163	4	13011-74410
TOYOTA	NPR Piston Ring	SWT10144ZZ	3VZ-F	2958	V-6	13011-62060 13011-65021
			3VZ-FE			
TOYOTA	NPR Piston Ring	SWT10148ZZ	3VZ-FE	2958	V-6	13011-62040
TOYOTA	NPR Piston Ring	SWT10177ZZ	1MZ	2994	6	13011-20020
TOYOTA	NPR Piston Ring	SWT10177ZZ	2MZ	2994	6	13011-20010 13011-20012 13011-20050
TOYOTA	NPR Piston Ring	SWT10147ZZ	1UZ-FE	3968	V-8	13011-50040
TOYOTA	NPR Piston Ring	SWT10022ZZ	3R	1897	4	13011-49010 13011-49021
TOYOTA	NPR Piston Ring	SWT10069ZZ	5R	1994	4	13011-44043 13011-44010 13011-44011 13011-44030 13011-44031 (777) 13011-44032 13011-44040 13011-44041 (500) 13011-44042 (777) 13011-44060 (777) 13011-44061 13011-44062 13011-44063 13011-44073
TOYOTA	NPR Piston Ring	SJT10043ZZ	16R	1808	4	13011-38040
			18R	1968		
			19R	1968		
			20R	2189		
TOYOTA	NPR Piston Ring	SWT10043ZZ	16R	1808	4	13011-30030 13011-34012 (Mt.777) 13011-34013 13011-34020 13011-34021 13011-34022 (Mt.777) 13011-34023 13011-34030 13011-34050 13011-38010 13011-38020 13011-38040 13011-38060
			18R	1968		
			19R	1968		
			20R	2189		
TOYOTA	NPR Piston Ring	SJT10063ZZ	20R	2189	4	13011-38030

TOYOTA	NPR Piston Ring	SDT10172ZZ	2AZ-FE	2362	4	13011-28100 13011-28141
TOYOTA	NPR Piston Ring	SWT10182ZZ	2AZ-FE	2362	4	13011-28101 13011-28102
TOYOTA	NPR Piston Ring	SDT10187ZZ	2AZ-FSE	2362	4	13011-28180
TOYOTA	NPR Piston Ring	SWT10026ZZ	F	3878	6	13011-69021 13011-60011
TOYOTA	NPR Piston Ring	SWT10044ZZ	F(NEW)	3878	6	13011-60040
TOYOTA	NPR Piston Ring	SWT10111ZZ	4Y	2237	4	13011-73020 13011-73030 13011-73040 13011-73042
TOYOTA	NPR Piston Ring	SWT10077ZX	22R	2189	4	13011-35010 13011-35020 13011-35030
TOYOTA	NPR Piston Ring	SWT10103ZZ	22R	2189	4	13011-35040 13011-35050 13011-35060 13011-35061 13011-35070 13011-35071
			22R-E			
TOYOTA	NPR Piston Ring	SWT10048ZZ	5P	2771	4	13011-96102
TOYOTA	NPR Piston Ring	SWT10178ZZ	5VZ	3378	6	13011-62100 13011-62110 13011-66020
TOYOTA	NPR Piston Ring	SWT10049ZZ	2F	4230	6	13011-61010
TOYOTA	NPR Piston Ring	SWT10106ZZ	3F	3995	6	13011-61060
TOYOTA	NPR Piston Ring	SWT10151ZZ	3F(NEW)	3955	6	13011-61062
TOYOTA	NPR Piston Ring	SWT10195ZZ	1GR	3956	6	
TOYOTA	NPR Piston Ring	SDT10194ZY	2GR-FSE		6	13011-31140 13011-31130
TOYOTA	NPR Piston Ring	SWT10203ZZ	2UZ-FE	4663	8	13011-50140

TOYOTA	NPR Piston Ring	SWT10127ZZ	2TZ	2438	4	13011-76010 13011-76050
TOYOTA	NPR Piston Ring	SWT10139ZZ	3RZ-FE	2693	4	13011-75040-A
TOYOTA	NPR Piston Ring	SDT10193ZY	2TR	2693	4	13011-75130 13011-75110
TOYOTA	NPR Piston Ring	SWT10168ZZ	1FZ	4476	6	13011-66020
TOYOTA	NPR Piston Ring	SWT10184ZZ	1FZ	4476	6	13011-66021