

Car Type	Product	TPR NO.	Type	Engine Model	CC	NO. Cyl.	Reference
TOYOTA	TPR Piston Ring	35591	3F	1SZ-FE	1000	4	13011-23041
TOYOTA	TPR Piston Ring	35878	3F	1E	1000	4	13011-10070
				1E-L			13011-10080
							13011-10081
TOYOTA	TPR Piston Ring	35823	3F	2K	993	4	13011-12010 13011-12030 13011-12031
TOYOTA	TPR Piston Ring	36006	2FAC	1ND		4	13011-33041
TOYOTA	TPR Piston Ring	35879	3F	2E-U	1295	4	13011-11040
				2E-C			13011-11041
							13011-11060
							13011-11061
							13011-11072
TOYOTA	TPR Piston Ring	35919	3F	2E- 2	1295	4	13011-11064
TOYOTA	TPR Piston Ring	35883	3F	3E	1300	4	13011-11080 13011-11090
TOYOTA	TPR Piston Ring	35954	3F	4E,5E	1300	4	13011-11122 13011-11140 13011-11160
TOYOTA	TPR Piston Ring	35884	3F	1N-T	1453	4	13011-55010
				1N			13011-55011
TOYOTA	TPR Piston Ring	35815	3F	3K	1077	4	13011-22011
				K			13011-24010
							13011-24011
							13011-24012
							13011-24020
							13011-24030
TOYOTA	TPR Piston Ring	35863	3F	4K	1290	4	13011-13010
				4K-V(EC)			13011-13060
TOYOTA	TPR Piston Ring	35896	3F	4K-C	1290	4	13011-13030
TOYOTA	TPR Piston Ring	35816	3F	M	1988	6	13011-41015
				2M			13011-41040
TOYOTA	TPR Piston Ring	35858	3F	1G	1988	6	13011-70010
				1G-E			
				1G-G			
				1G-G2			
TOYOTA	TPR Piston Ring	36003	3F	1G-E	1988	6	13011-70030
TOYOTA	TPR Piston Ring	35981	3FAC	1GX	2000	6	13011-70051
				1G-GE			
TOYOTA	TPR Piston Ring	35973	2F	1NZ-FXE	1496	4	13011-21030 13011-21070
TOYOTA	TPR Piston Ring	35974	3F	2NZ-FE	1298	4	13011-21050
TOYOTA	TPR Piston Ring	35975	3FAC	2NZ-FE-2	1298	4	13011-21060
TOYOTA	TPR Piston Ring	35857	3F	2A	1295	4	13011-14010 13011-14020 13011-14021
TOYOTA	TPR Piston Ring	35822	3F	3P	1345	4	13011-23010
				4P			13011-23030
TOYOTA	TPR Piston Ring	35854	3F	1A	1452	4	13011-15010
				3A			13011-15011
							13011-15020
							13011-15021
							13011-15031

TOYOTA	TPR Piston Ring	35811	3F	2R	1490	4	13011-31010 13011-31030 13011-31040
TOYOTA	TPR Piston Ring	35894	3F	5A	1498	4	13011-15050
TOYOTA	TPR Piston Ring	35920	3F	5A-F	1500	4	13011-15120 13011-15100
TOYOTA	TPR Piston Ring	35939	3F	8A		4	13011-15130
TOYOTA	TPR Piston Ring	35950	3F	1,3,4ZZ	1794	4	13011-22030 13011-22040 13011-22100 13011-22111 13011-22200
TOYOTA	TPR Piston Ring	35824	3F	T	1407	4	13011-25010 13011-25020 13011-25032 13011-25041
TOYOTA	TPR Piston Ring	35864	3F	T-J T-U	1407	4	13011-25033 13011-25042
TOYOTA	TPR Piston Ring	35832	3F	4M	2563	6	13011-45021 13011-45040
TOYOTA	TPR Piston Ring	35830	3F	12R	1587	4	13011-31050 13011-31051 13011-31060 13011-31061 13011-31070 13011-31081 13011-31090
TOYOTA	TPR Piston Ring	35907	3FACBC	12R	1587	4	13011-31051 13011-31060 13011-31061 13011-31070 13011-31081 13011-31090
TOYOTA	TPR Piston Ring	35861	3F	1S-U 1S-L 5K	1832 1486	4	13011-63010 13011-63011 13011-63020 13011-63030 13011-36031 13011-13040 13011-13050 13011-13080 13011-13090
TOYOTA	TPR Piston Ring	35922	3F	7K	1781	4	13011-13100
TOYOTA	TPR Piston Ring	35876	3F	4A 4A-G 4A-L 4A-C	1587	4	13011-16011 13011-16031 13011-16032 13011-16010
TOYOTA	TPR Piston Ring	35908	3F	4AF	1600	4	13011-16130 13011-16140 13011-16150
TOYOTA	TPR Piston Ring	35913	3F	4AFE	1600	4	13011-16290 13011-16300 13011-16280

TOYOTA	TPR Piston Ring	35951	3F	4AGEU	1600	4	13011-16050 13011-16090 13011-16180
TOYOTA	TPR Piston Ring	35910	3F	4AGE	1587	4	13011-16200 13011-16210
TOYOTA	TPR Piston Ring	35976	3F	4AG	1587	4	13011-16350
TOYOTA	TPR Piston Ring	35989	3F	N4AG	1600	4	13011-16230
TOYOTA	TPR Piston Ring	35938	3F	7A-FE	1762	4	13011-16320 13011-16330
TOYOTA	TPR Piston Ring	35977	2FAC	1CD		4	13011-27030
TOYOTA	TPR Piston Ring	35996	2FAC	1CDA	2000	4	13011-27040
TOYOTA	TPR Piston Ring	35917	3F	4S	1838	4	13011-74110 13011-74120 13011-74121
TOYOTA	TPR Piston Ring	35859	3F	5M	2759	6	13011-43010 13011-43030
				5M-E(U)			
TOYOTA	TPR Piston Ring	35860	3F	5M-GEU	2759	6	13011-43050 13011-43080
				5N-GE			
				(ECE)			
TOYOTA	TPR Piston Ring	35893	3F	7M	2954	6	13011-42010 13011-42020 13011-42030 13011-42040
TOYOTA	TPR Piston Ring	35842	3F	4V	3376	8	13011-52010
TOYOTA	TPR Piston Ring	35865	2FAC	1C	1839	4	13011-64010 13011-64020 13011-64040 13011-64070 13011-64080
				1C-T			
TOYOTA	TPR Piston Ring	35900	3FAC	1C-A	1839	4	13011-64130 13011-64220
TOYOTA	TPR Piston Ring	35923	2FAC	1C-T	1839	4	13011-64070
TOYOTA	TPR Piston Ring	35853	3F	21R	1972	4	13011-37030 13011-37050 13011-37060
				21R-U			
TOYOTA	TPR Piston Ring	35880	3F	21R-2	1972	4	13011-37070 13011-37071
				21R-C			
				21R-V			
TOYOTA	TPR Piston Ring	35866	3F	2S	1995	4	13011-74010 13011-74020 13011-74030 13011-74040 13011-74041
				2S-C			
TOYOTA	TPR Piston Ring	35825	3F	2T	1588	4	13011-26020 13011-26040 13011-26041 13011-27020
				2T-G			
				3T			
				12T			
TOYOTA	TPR Piston Ring	35958	3F	3T		4	13011-28010 13011-28011 13011-28012 13011-28020 13011-28030 13011-28031 13011-28070 13011-28071

TOYOTA	TPR Piston Ring	36009	2FAC	1,2DZ		4	13011-78202-71
TOYOTA	TPR Piston Ring	35960	2F	1TR	2000	4	13011-75100 13011-75120
TOYOTA	TPR Piston Ring	35820	3F	6R	1707	4	13011-33010 13011-33020 13011-33021 13011-33022 13011-33030
				7R			
				8R			
					1591		
					1858		
TOYOTA	TPR Piston Ring	35902	3F	3S	1998	4	13011-74070 13011-74072 13011-74091
TOYOTA	TPR Piston Ring	35885	3F	3SFE( C )	1998	4	13011-74080 13011-74081
TOYOTA	TPR Piston Ring	35942	3F	3S-F	1998	4	13011-74131
TOYOTA	TPR Piston Ring	35984	3F	3S-FE	1998	4	13011-74320 13011-74340 13011-74361
TOYOTA	TPR Piston Ring	35962	2FAC	3S-FSE	2000	4	13011-74400
TOYOTA	TPR Piston Ring	35995	3F	3S-G	2000	4	13011-88363 13011-88380
TOYOTA	TPR Piston Ring	35963	3F	1AZ	2000	4	13011-28120
TOYOTA	TPR Piston Ring	35997	2FAC	1AZ-D4	2000	4	13011-28110
TOYOTA	TPR Piston Ring	35904	3F	1RZ	1998	4	13011-75020
TOYOTA	TPR Piston Ring	35869	3FAC	1Y	1626	4	13011-71010 13011-71020 13011-71030 13011-71031 13011-71040 13011-71033
				2Y	1812		
				3Y	1998		
TOYOTA	TPR Piston Ring	35930	3FAC	1Y(NEW)	1626	4	13011-71033
				2Y	1998		
				3Y			
TOYOTA	TPR Piston Ring	35946	3F	2JZ-GE	2997	6	13011-46040 13011-46041
TOYOTA	TPR Piston Ring	35964	2FAC	2JZ-D4	2997	6	13011-46060 13011-46061
TOYOTA	TPR Piston Ring	35877	3FAC	2C-T	1974	4	13011-64150 13011-64060
TOYOTA	TPR Piston Ring	35911	2FAC	2C-A	1974	4	13011-64170
TOYOTA	TPR Piston Ring	35924	2FAC	2C-2	1974	4	13011-64190
TOYOTA	TPR Piston Ring	35965	2FAC	2C-T-2	1974	4	13011-64210
TOYOTA	TPR Piston Ring	35912	2FAC	2.3C-T	2000	4	13011-64212 13011-64213
TOYOTA	TPR Piston Ring	35966	2FAC	3C-T	2200	4	13011-64230

TOYOTA	TPR Piston Ring	35925	2FAC	1DZ	2184	4	13011-78200-71
TOYOTA	TPR Piston Ring	35940	2FAC	2DZ	2184	4	13011-78201-71
TOYOTA	TPR Piston Ring	36000	3F	Y-P	2000	4	13011-73071
TOYOTA	TPR Piston Ring	35988	3FAC	5S-FE	2163	4	13011-74150
TOYOTA	TPR Piston Ring	35921	3FAC	5SFE2	2163	4	13011-74290 13011-74260 13011-74261
TOYOTA	TPR Piston Ring	35943	3FAC	5SFE2-2	2163	4	13011-74300
TOYOTA	TPR Piston Ring	35944	3F	5SFE3	2163	4	13011-74370
TOYOTA	TPR Piston Ring	35935	3F	1MZ-FE	2994	6	13011-20010 13011-20012 13011-20020
TOYOTA	TPR Piston Ring	35947	3F	1UZ-FE	3968	8	13011-50040
TOYOTA	TPR Piston Ring	35948	3FAC	1UZ-FE-2	3968	8	13011-50060
TOYOTA	TPR Piston Ring	35998	2FAC	3GR-D4	3000	6	13011-31110
TOYOTA	TPR Piston Ring	35934	3F	3VZ-FE	2958	6	13011-62060 13011-65021
TOYOTA	TPR Piston Ring	35810	3F	5R	1994	4	13011-44011 13011-44032 13011-44040 13011-44042 13011-44043 13011-44060 13011-44061 13011-44062 13011-44063 13011-44073
TOYOTA	TPR Piston Ring	35905	3FAC	5R	1994	4	13011-44011 13011-44032 13011-44040 13011-44042 13011-44043 13011-44060 13011-44061 13011-44062 13011-44063 13011-44073
TOYOTA	TPR Piston Ring	35813	3PSBC	J 2J	2336	4	13011-46021
TOYOTA	TPR Piston Ring	35837	2F3PS	J 2J	2481	4	13011-48013 13011-48021
TOYOTA	TPR Piston Ring	35838	2FAC	2J(NEW)	2481	4	13011-48022 13011-48023 13011-48030
TOYOTA	TPR Piston Ring	35827	3PSBC	H	3576	6	13011-47020
TOYOTA	TPR Piston Ring	35848	2F3PS	H	3576	6	13011-47021
TOYOTA	TPR Piston Ring	35839	2FAC	H(NEW)	3576	6	13011-47022 13011-47023

TOYOTA	TPR Piston Ring	35831	3F	18R	1808	4	13011-38010
				16R			13011-38020
				20R			13011-38040
				18R-G	1968		13011-38060
				20R			13011-34012
				18R	2189		13011-34013
TOYOTA	TPR Piston Ring	35849	2F3PS	20R	1968	4	13011-34020
				18R	2189		13011-34022
TOYOTA	TPR Piston Ring	35967	3F	2AZ-FE	2400	4	13011-34021
TOYOTA	TPR Piston Ring	35806	3F	F	3878	6	13011-34030
							13011-34050
TOYOTA	TPR Piston Ring	35835	3F	F(NEW)	3878	6	13011-38030
TOYOTA	TPR Piston Ring	35850	2FAC	L	2188	4	13011-28151
							13011-60011
							13011-69021
TOYOTA	TPR Piston Ring	35862	2FAC	L(NEW)	2188	4	13011-60040
							13011-54010
							13011-54020
							13011-54021
TOYOTA	TPR Piston Ring	35887	3FAC	4Y	2208	4	13011-54030
							13011-54031
							13011-54032
							13011-54040
							13011-54041
							13011-54042
							13011-54080
TOYOTA	TPR Piston Ring	35932	3FAC	4Y(NEW)	2208	4	13011-73020
							13011-73030
							13011-73031
							13011-73032
							13011-73040
TOYOTA	TPR Piston Ring	35856	2FACBC	2H	3980	6	13011-73032
							13011-96601
							13011-68010
							13011-68020
TOYOTA	TPR Piston Ring	35886	2FAC	12H-T	3980	6	13011-68030
TOYOTA	TPR Piston Ring	35986	2FAC	2KD		4	13011-30030
TOYOTA	TPR Piston Ring	35852	3FACBC	22R	2400	4	13011-35010
				22R-A			13011-35020
				22R-B			13011-35030
TOYOTA	TPR Piston Ring	35881	3FAC	22R-2	2400	4	13011-35040
				22R-E			13011-35050
							13011-35052
							13011-35060
							13001-35061
							13011-35070
TOYOTA	TPR Piston Ring	35933	3FAC	22R-3	2400	4	13011-35071

TOYOTA	TPR Piston Ring	35945	3FAC	22R-4	2400	4	13011-35041
TOYOTA	TPR Piston Ring	35867	2FAC	2L	2446	4	13011-54050 13011-54060 13011-54061 13011-54100
TOYOTA	TPR Piston Ring	35899	2F	2L-T		4	13011-54090
TOYOTA	TPR Piston Ring	35959	3F	5VZ-FE	3378	6	13011-62100
TOYOTA	TPR Piston Ring	35836	3F	2F	4230	6	13011-61010
TOYOTA	TPR Piston Ring	35882	3FAC	3F	4000	6	13011-61060 13011-61061
TOYOTA	TPR Piston Ring	35914	3FAC	3F(NEW)	4000	6	13011-61062
TOYOTA	TPR Piston Ring	35968	3F	1GR-FE		6	13011-31100
TOYOTA	TPR Piston Ring	35898	2FAC	1HZ	4200	6	13011-17010 13011-17011 13011-17020 13011-17030
TOYOTA	TPR Piston Ring	35970	2FAC	1HD-FTE	4200	6	13011-17040
TOYOTA	TPR Piston Ring	35949	2FAC	1PZ	3500	5	13011-18030
TOYOTA	TPR Piston Ring	36002	3F	2GR-FE	3500	6	13011-31130
TOYOTA	TPR Piston Ring	35999	3F	2GR-FE	3500	6	13011-31130
TOYOTA	TPR Piston Ring	35952	3FAC	2,3RZ	2438	4	13011-75030 13011-75060
TOYOTA	TPR Piston Ring	35956	3F	2TZ-FE	2438	4	13011-76050 13011-76030
TOYOTA	TPR Piston Ring	36004	3FAC	3RZ-FE	2693	4	13011-75040
TOYOTA	TPR Piston Ring	35961	2F	2TR-EF	2700	4	13011-75110 13011-75130
TOYOTA	TPR Piston Ring	35834	2F3PS	B(OLD)	2977	4	13011-56010
TOYOTA	TPR Piston Ring	35847	2F3PS	B	2977	4	13011-56011
TOYOTA	TPR Piston Ring	35840	2FAC	B(NEW)	2977	4	13011-56012 13011-56013 13011-56021 13011-56022
				BK			
TOYOTA	TPR Piston Ring	35889	2FAC	11B	2977	4	13011-56030
TOYOTA	TPR Piston Ring	35901	2FAC	11B,B	2977	4	13011-56040
TOYOTA	TPR Piston Ring	35971	2FAC	11B-2	2977	4	13011-56050
TOYOTA	TPR Piston Ring	35892	2FAC	3L	2779	4	13011-54120

TOYOTA	TPR Piston Ring	35987	2FAC	1KD	2982	4	13011-30020 13011-30022 13011-30040 13011-30050
TOYOTA	TPR Piston Ring	35937	2FAC	1KZ	2982	4	13011-67030
TOYOTA	TPR Piston Ring	35915	2FAC	1Z	2977	4	13011-78300-71
TOYOTA	TPR Piston Ring	35928	2FAC	2Z		4	13011-78700-71
TOYOTA	TPR Piston Ring	36010	2FAC	2Z-B		4	13011-78701-71
TOYOTA	TPR Piston Ring	35929	2FAC	5L	2985	4	13011-54130
TOYOTA	TPR Piston Ring	35941	3FAC	1FZ	4476	6	13011-66021
TOYOTA	TPR Piston Ring	35855	2FAC	3B	3431	4	13011-58010
TOYOTA	TPR Piston Ring	35909	2FAC	3BK	3431	4	13011-58011
TOYOTA	TPR Piston Ring	35890	2FAC	13B	3400	4	13011-58030
TOYOTA	TPR Piston Ring	35891	2FAC	13BT	3431	4	13011-58040
TOYOTA	TPR Piston Ring	35895	2FAC	14B 3B	3660	4	13011-58050 13011-58051
TOYOTA	TPR Piston Ring	35903	2F	14B-T	3660	4	13011-58060
TOYOTA	TPR Piston Ring	35916	2FAC	14B(NEW)	3660	4	13011-58070 13011-58072
TOYOTA	TPR Piston Ring	35808	PS	2D(OLD)	6494	6	13011-77010 13011-77020 13011-77021 13011-77022 13011-77023
TOYOTA	TPR Piston Ring	35841	2F3PS	2D	6494	6	13011-77024
TOYOTA	TPR Piston Ring	35846	2FBC	2D(NEW)	6494	6	13011-77040 13011-77041 13011-77050
TOYOTA	TPR Piston Ring	35926	2FAC	15B-F	4104	4	13011-58090
TOYOTA	TPR Piston Ring	35969	2FAC	15B-FTE	4100	4	13011-58110